

Xtreamer xUSB virtual CD-ROM removal

Requirements

- Xtreamer USB Flash Drive (xUSB).
- A computer running Windows OS (Win 2k/XP/Vista/7) equipped with a USB port.
- “uDisk Tool” program.

Warning!!

This instruction includes format commander that will delete all data.
Please don't forget to backup data.

Instructions

1. Download [uDiskTool](#) utility and save on the Desktop
2. Connect xUSB to a USB port.
3. Execute uDisk Tool utility.




4. Click CD icon once utility starts.



5. Click "Burn" icon on Partition Setting window.

Note: all data on USB will be deleted.



6. Virtual CD-ROM partition removal proceeds.

7. Check that CD-ROM partition was removed from the USB.

8. Safely remove xUSB.